



“Anything Else Is Just a Stinkin’ Rag!”™

HELPFUL TIPS:

1. First, remove hockey skates.
2. With one hand, hold the skate at a vertical angle, while the back (heel) of the skate boot is braced on knee.
3. It is important that the blade be at a vertical angle to allow for proper ice and water runoff.
4. Line the top of the skate blade up with the notch on either end of the Original Skate Squeegee. Young children may require assistance!
5. Begin to slide the Original Skate Squeegee **SLOWLY** over the skate blade, while applying light downward pressure to ensure the entire blade is being cleaned and dried.
6. If the skate blade is cold, condensation will occur. It is recommended that the Original Skate Squeegee be used a second time after the blades begin to adjust to room temperature.
7. Lightly tap out any ice or water from the skate squeegee, and then repeat on the other skate blade.

For best results, slide **SLOWLY** over the skate blade while blade is at an angle. You should be able to hear the squeegees making a squeaking sound. Do not reverse direction while wiping the blade. Use the Original Skate Squeegee in conjunction with proper blade covers.

Fun Fact: The Original Skate Squeegee was invented and designed by a Minnesota youth hockey coach, to prevent his son’s hands from being cut or injured while drying his hockey skate blades. Since then, the Original Skate Squeegee has evolved into a popular hockey skate accessory that kids all over the U.S. and Canada carry inside their hockey bags. For more information, please visit their website at www.originalskatesqueegee.com.